

WIRING SCHEMATIC - ELECTRIC SPREADER (On/Off Control)

**NOTE: SEE PAGE 29
FOR SERVICE PARTS
DETAIL**

